

## **RADIO DAILY MAINTENANCE**

**STEP ONE:** Rinse entire radio under a tap or place in a bucket of fresh water.

**STEP TWO:** Pat dry with a towel.

**STEP THREE:** Ensure radio is fully dry before placing back in charger.

## **ADDITIONAL MAINTENANCE**

**STEP ONE:** To improve radio lifespan every 1-2 months add 1 drop of liquid detergent to a bucket of fresh water and gently scrub the radio.

**STEP TWO:** Allow to fully dry before reassembling.



**DO NOT RE-INSERT OR CHARGE BATTERY IF WET!**

**ADHERE TO THE SPECIFIC RADIO PROCEDURES ESTABLISHED BY EACH CLUB**

**GWN IS A MANAGED SERVICE. PLEASE DO NOT MARK, ENGRAVE, OR LABEL THE RADIOS**

**RADIO FAULT MANAGEMENT**

If you encounter any issues with your GWN radio or accessories, please contact:

**Telstra Service Desk**

**1800 998 852**