

RADIO DAILY MAINTENANCE

STEP ONE: Rinse entire radio under a tap or place in a bucket of fresh water.

STEP TWO: Pat dry with a towel.

STEP THREE: Ensure radio is fully dry before placing back in charger.

ADDITIONAL MAINTENANCE

STEP ONE: To improve radio lifespan every 1-2 months add 1 drop of liquid detergent to a bucket of fresh water and gently scrub the radio.

STEP TWO: Allow to fully dry before reassembling.



DO NOT RE-INSERT BATTERY IF WET!

ADHERE TO THE SPECIFIC RADIO PROCEDURES ESTABLISHED BY EACH CLUB

GWN IS A MANAGED SERVICE. PLEASE DO NOT MARK, ENGRAVE, OR LABEL THE RADIOS

RADIO FAULT MANAGEMENT

If you encounter any issues with your GWN radio or accessories, please contact:

Telstra Service Desk

1800 998 852